Straight RJ-12
From SARMU
DB-9/RJ-12
Adapter

From ENDEC Decoder
Active or Previous
Star-8 Bank

To G From ENDEC Audio Common

To L+ From ENDEC Speaker Line Out

Straight
RJ-12

To G From ENDEC Audio Common

To L+ From ENDEC Speaker Line Out

Straight
RJ-12

To G From ENDEC Audio Common

To L+ From ENDEC Speaker Line Out

Straight
RJ-12

To G From ENDEC Audio Common

To L+ From ENDEC Speaker Line Out

Straight
RJ-12

To G From ENDEC Audio Common

To L+ From ENDEC Speaker Line Out

To Next Bank If Applicable