
ENDEC
Speaker Line out
Decoder
Active
Comm 2
Comm 3
Comm 6
Null Modem
Serial
ENDEC Audio Line In & Audio
Common to Star-8 EAS IN
Loop to each successive Star-8 per
other drawings or manual
To Serial 2
B
A
G & CT
Star-8 Bank A Master
C0 & C1
Master to Serial RJ-12
B
A
G & CT
Star-8 Bank A Slave
C0 & C1
RJ-12
A
B
G & CT
Star-8 Bank A Slave
C0 & C1
RJ-12
B
A
G & CT
Star-8 Bank A Slave
C0 & C1
RJ-12
A
B
G & CT
Star-8 Bank A Slave
C0 & C1
830EAS CG
Serial 1